

Wanneer de stekker in randgeaarde WCD wordt geplaatst, zal de pomp starten in de fabrieksinstelling "Constante druk, AutoAdapt". Deze instelling is speciaal voor vloerverwarming geselecteerd. Het benodigd vermogen wordt door de pomp zelf berekend en verdere handelingen zijn niet nodig.

Uiteraard dient de pomp zoals alle z.g. natlopers, te allen tijde te draaien zodra deze onder water staat. Ook als de installatie (nog) niet is opgeleverd dient de pomp te blijven draaien. Het vastzitten van de as wordt hiermee voorkomen. Indien de pomp in natte toestand zonder stroom komt, vervalt de garantie.



FAULT	OPERATING PANEL	REMEDY
OFF 0 V		A: Check power supply connection. B: Turn power switch ON. C: Check cable connection.
ON 230 V		1: Check power supply connection. 2: Turn power switch ON. 3: Tighten the pump housing (5mm screwdriver, No.2).
ON <160 V		Check power supply connection.
ON 230 V		1: Check power supply connection. 2: Turn power switch ON. 3: Tighten the pump housing. 4: Check the pump is not blocked.